

# ANDI-TOOL

## INSTALLATION GUIDE of ANDI-TOOL

May 2021

## CONTENT

1	INTRODUCTION.....	3
2	REQUIREMENTS TO RUNNING SYSTEM.....	3
3	Software.....	4
3.1	ANDI Tool .....	4
3.2	Extra needed software and drivers .....	4
3.3	Installation.....	4
4	ANDI-Support.....	5
5	Licenses.....	6
5.1	ANDi-Tool - old installation process (only internal usage).....	6
5.2	ANDi-tool (standard installation).....	7
6	Troubleshooting .....	8
6.1	Valid dongle-license is not working.....	8
7	CHANGELOG .....	10
8	CONTACT.....	11



## 1 INTRODUCTION

ANDi-tool is a test and simulation environment for Ethernet electronic control units (100BASE-T1 and 1000BASE-T1) and for the CAN/CAN-FD, LIN and FlexRay bus systems. The ANDi environment supports electronic control unit developers with the validation of their ECU functions by means of generated residual bus simulations and intelligent message generators. A traffic viewer with signal graph display and seamless support of automotive databases (Fibex, ARXML, DBC, LDF) makes it most flexible and practical. Through the support of Technica Engineering hardware, other hardware and “.net” extensions, ANDi can be used as a powerful tool for complex ECU testing and test automation.




## 2 REQUIREMENTS TO RUNNING SYSTEM

Following requirements has to be taken into account to run ANDi-tool:




### Minimum hardware configuration:

-  8 GB memory
-  8 GB hard disk space

### recommended hardware configuration:

-  16 GB memory
-  64 GB hard disk space
-  SSD

### Supported operating systems:

-  Windows 8 64bit
-  Windows 10 64bit
-  Windows server 2012 64bit

**Note:** For not listed operating systems no support will be provided by Technica Engineering.

**Note:** ANDi-tool doesn't work on virtual machines.

## 3 Software

### 3.1 ANDI Tool

You can download the latest **ANDi-tool software** from the following link:

<https://files.technica-engineering.de/ANDi/>

If you have a license (see Chapter 5) for the **dongle version**, please download the latest version with “**dongle**” in the file-name.

### 3.2 Extra needed software and drivers

ANDi is a windows application and requires the following software packages to be installed on the machine with ANDi installed to function properly. The software can be downloaded from the following link, too:

<https://files.technica-engineering.de/ANDi/Redistributables>

- Microsoft .Net Framework at least v4.6.2
- WinPcap v4.1.3

For **ANDi-Tool dongle version** please download following software, too:

- CodeMeterRuntime64

**Note:** It is recommended to download the complete CodeMeter Runtime-Kit. This is available on the homepage from CodeMeter:

<http://codemeter.com/>

### 3.3 Installation

- First install all extra needed software and drivers.
- Then install ANDi-Tool.

## 4 ANDI-Support

To avoid potential problems which could have been already fixed, please make sure to use the last official version of ANDi. You can report any problem by sending an email to: [support@technica-engineering.de](mailto:support@technica-engineering.de) and providing the following information:

- Steps to reproduce the problem (If reproducible)
- ANDi version and Platform (Windows 7, 10...)
- ANDi log files under:  
`%appdata%\ANDi\Logs(C:\Users\YOUR_USERNAME\AppData\Roaming\ANDi\Logs)`

In addition to the help manual within ANDi, there are other useful sources for helping with ANDi. You can contact us and ask your questions by email to: [support@technica-engineering.de](mailto:support@technica-engineering.de)

## 5 Licenses

There are two different versions of ANDi-Tool:

- ↳ SetupANDI\_v0.8.xx.exe
- ↳ SetupANDI\_v0.8.xx\_Dongle.exe (trial-version not possible)

### 5.1 ANDi-Tool - old installation process (only internal usage)

After installation please start ANDi-Tool. At the beginning you will be asked for a license. Now you can see a product number:




Figure 5–1: Product number of ANDi-Tool

Copy this product number and send an Email to [support@technica-engineering.de](mailto:support@technica-engineering.de) to request a trial license or if you have already purchased a license, send an Email with your order number/delivery number to [support@technica-engineering.de](mailto:support@technica-engineering.de).

**Note:** The product number is generated on your PC and it is fixed to your PC. It is not possible to change your PC and use the same license.

**Note:** for trial licenses: we offer our software products to other businesses or freelancers, rather than private persons. Please send us your request by your company-email-address with business contact information. Then we will provide you your trial license.

## 5.2 ANDi-tool (standard installation)

For this version you need an ANDi-tool-license and an USB-dongle. Both will be provided by Technica Engineering. The license is fixed to the dongle. The dongle works only with an installed ANDi-tool dongle-version. Please plug in the dongle before starting ANDi-tool dongle version.


## 6 Troubleshooting

### 6.1 Valid dongle-license is not working

It is possible, that a dongle with valid license is not working. To check if the clock in the dongle is up to date please do following:


**Note:** Complete CodeMeter Runtime-Kit must be installed.

1. Plug in your dongle
2. Run CodeMeter Control Center
3. Now this screen should be available



1) This is the number of your dongle. You can see it on your dongle

4. Please start WebAdmin 2)




Here you can see the licenses on the dongle and if they are green, everything is fine with the licenses. If the line is red there are two possibilities:  
First: Your license is not valid anymore.



Second: The internal clock of the dongle is not up to date, then please follow the next steps.

5. Go to the tab CmContainer Infos **1)** and press update **2)**:



Now it should be green as shown in the point 4.

For further support please contact [support@technica-engineering.de](mailto:support@technica-engineering.de)

## 7 CHANGELOG

Version	Chapter	Description	Date
1.0	All	First release	19.11.2018
1.1	5, 6	Added chapter 5 and 6	21.11.2018
1.2	2	Requirements reworked	15.10.2019
1.3	2	Requirements reworked	Apr 2020
1.4	2	Requirements reworked	May 2021
1.4	3	Links updated	May 2021
1.5	All	Exchange from email ANDi@technica to support@technica	Jun 2021

## 8 CONTACT

If you have any questions regarding this product, please feel free to contact us:

Technica Engineering GmbH  
Leopoldstr. 236  
80807 München  
Germany

Fax: +49-89-34290265

[Info@technica-engineering.de](mailto:Info@technica-engineering.de)

[www.technica-engineering.de](http://www.technica-engineering.de)